

Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.

SAMSUNG ELECTRONICS



World Wide Web
<http://www.samsungmobile.com>

Printed in Korea
Code No.:GH68-26720A
English (IND). 04/2010. Rev.1.2

GT-C3510 user manual



using this manual

This user manual has been specially designed to guide you through the functions and features of your mobile phone. To get started quickly, refer to “introducing your mobile phone,” “assembling and preparing your mobile phone,” and “using basic functions.”

Instructional icons

Before you start, familiarise yourself with the icons you will see in this manual:



WARNING

Warning—situations that could cause injury to yourself or others



CAUTION

Caution—situations that could cause damage to your phone or other equipment



Note—notes, usage tips, or additional information



Refer to—pages with related information; for example: ► p. 12 (represents “see page 12”)

- **Followed by**—the order of options or menus you must select to perform a step; for example: In Menu mode, select **Messages** → **Create new message** (represents **Messages**, followed by **Create new message**)
- [] **Square brackets**—phone keys; for example: [] (represents the Power/Menu exit key)

Copyright information

Rights to all technologies and products that comprise this phone are the property of their respective owners:

- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide.
Bluetooth QD ID: B016092
- Java™ is a trademark of Sun Microsystems, Inc.

CE0168

contents

safety and usage information	1
Safety warnings	1
Safety precautions	4
Important usage information	6
 introducing your mobile phone	 12
Unpack	12
Phone layout	13
Keypad	14
Icons	14
 assembling and preparing your mobile phone	 16
Install the SIM card and battery	16
Charge the battery	18
Insert a memory card (optional)	19
Attach a hand strap (optional)	19

using basic functions 20

Turn your phone on and off	20
Use the touch screen	21
Access menus	22
Use widgets	22
Customise your phone	23
Use basic call functions	25
Send and view messages	26
Add and find contacts	29
Use basic camera functions	30
Listen to music	31
Browse the web	33
Use the Google services	34

using advanced functions 36

Use advanced call functions	36
Use advanced phonebook functions	39
Use advanced messaging functions	40

Use advanced camera functions	42
-------------------------------------	----

Use advanced music functions	45
------------------------------------	----

using tools and applications 48

Use the Bluetooth wireless feature	48
Activate and send an SOS message	50
Use the mobile tracker 2.0	51
Make fake calls	53
Record and play voice memos	54
Edit images	54
Print images	56
View photos and videos on the web	57
Use Java-powered games and applications	57
Synchronise data	58
Create and view world clocks	59
Set and use alarms	59
Use the mobile prayer feature	60

Use the calculator	60
Convert currencies or measurements	61
Set a countdown timer	61
Use the stopwatch	61
Look up words in a dictionary	61
Create a new task	62
Create a new memo	62
Manage your calendar	63
troubleshooting	a

safety and usage information

Comply with the following precautions to avoid dangerous or illegal situations and ensure peak performance of your mobile phone.



Safety warnings

Keep your phone away from small children and pets

Keep your phone and all accessories out of the reach of small children or animals. Small parts may cause choking or serious injury if swallowed.

Protect your hearing



Excessive exposure to sound at high volumes can cause hearing damage. Always turn the volume down before plugging the earphones into an audio source and use only the minimum volume setting necessary to hear your conversation or music.

Install mobile phones and equipment with caution

Ensure that any mobile phones or related equipment installed in your vehicle are securely mounted. Avoid placing your phone and accessories near or in an air bag deployment area. Improperly installed wireless equipment can cause serious injury when air bags inflate rapidly.

Handle and dispose of batteries and chargers with care

- Use only Samsung-approved batteries and chargers specifically designed for your phone. Incompatible batteries and chargers can cause serious injuries or damage to your phone.
- Never dispose of batteries or phones in a fire. Follow all local regulations when disposing of used batteries or phones.

- Never place batteries or phones on or in heating devices, such as microwave ovens, stoves, or radiators. Batteries may explode when overheated.
- Never crush or puncture the battery. Avoid exposing the battery to high external pressure, which can lead to an internal short circuit and overheating.

Avoid interference with pacemakers

Maintain a minimum of 15 cm (6 inches) between mobile phones and pacemakers to avoid potential interference, as recommended by manufacturers and the independent research group, Wireless Technology Research. If you have any reason to suspect that your phone is interfering with a pacemaker or other medical device, turn off the phone immediately and contact the manufacturer of the pacemaker or medical device for guidance.

Turn off the phone in potentially explosive environments

Do not use your phone at refuelling points (service stations) or near fuels or chemicals. Turn off your phone whenever directed by warning signs or instructions. Your phone could cause explosions or fire in and around fuel or chemical storage and transfer areas or blasting areas. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the phone, its parts, or accessories.

Reduce the risk of repetitive motion injuries

While using your phone, hold the phone with a relaxed grip, press the keys lightly, use special features that reduce the number of keys you have to press (such as templates and predictive text), and take frequent breaks.

Do not use the phone if the screen is cracked or broken

Broken glass or acrylic could cause injury to your hand and face. Bring the phone to a Samsung service centre to replace the screen. Damage caused by careless handling will void your manufacturer's warranty.



CAUTION

Safety precautions

Drive safely at all times

Avoid using your phone while driving and obey all regulations that restrict the use of mobile phones while driving. Use hands-free accessories to increase your safety when possible.

Follow all safety warnings and regulations

Comply with any regulations that restrict the use of a mobile phone in a certain area.

Use only Samsung-approved accessories

Using incompatible accessories may damage your phone or cause injury.

Turn off the phone near medical equipment

Your phone can interfere with medical equipment in hospitals or health care facilities. Follow all regulations, posted warnings, and directions from medical personnel.

Turn off the phone or disable the wireless functions when in an aircraft

Your phone can cause interference with aircraft equipment. Follow all airline regulations and turn off your phone or switch to a mode that disables the wireless functions when directed by airline personnel.

Protect batteries and chargers from damage

- Avoid exposing batteries to very cold or very hot temperatures (below 0° C/32° F or above 45° C/113° F). Extreme temperatures can reduce the charging capacity and life of your batteries.
- Prevent batteries from contacting metal objects, as this can create a connection between the + and - terminals of your batteries and lead to temporary or permanent battery damage.
- Never use a damaged charger or battery.

Handle your phone carefully and sensibly

- Do not disassemble your phone due to a risk of electric shock.
- Do not allow your phone to get wet—liquids can cause serious damage and will change the colour of the label that indicates water damage inside the phone. Do not handle your phone with wet hands. Water damage to your phone can void your manufacturer's warranty.
- Avoid using or storing your phone in dusty, dirty areas to prevent damage to moving parts.
- Your phone is a complex electronic device—protect it from impacts and rough handling to avoid serious damage.
- Do not paint your phone, as paint can clog moving parts and prevent proper operation.

CAUTION

- If your phone has a camera flash or light, avoid using it close to the eyes of children or animals.
- Your phone may be damaged by exposure to magnetic fields. Do not use carrying cases or accessories with magnetic closures or allow your phone to come in contact with magnetic fields for extended periods of time.

Avoid interference with other electronic devices

Your phone emits radio frequency (RF) signals that may interfere with unshielded or improperly shielded electronic equipment, such as pacemakers, hearing aids, medical devices, and other electronic devices in homes or vehicles. Consult the manufacturers of your electronic devices to solve any interference problems you experience.



Important usage information

Use your phone in the normal position

Avoid contact with your phone's internal antenna.

Allow only qualified personnel to service your phone

Allowing unqualified personnel to service your phone may result in damage to your phone and will void your warranty.

Ensure maximum battery and charger life

- Avoid charging batteries for more than a week, as overcharging may shorten battery life.
- Over time, unused batteries will discharge and must be recharged before use.

- Disconnect chargers from power sources when not in use.
- Use batteries only for their intended purpose.

Handle SIM cards and memory cards with care

- Do not remove a card while the phone is transferring or accessing information, as this could result in loss of data and/or damage to the card or phone.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.
- Frequent writing and erasing will shorten the life span of memory cards.
- Do not touch gold-coloured contacts or terminals with your fingers or metal objects. If dirty, wipe the card with a soft cloth.

Ensure access to emergency services

Emergency calls from your phone may not be possible in some areas or circumstances. Before travelling in remote or undeveloped areas, plan an alternate method of contacting emergency services personnel.

Specific Absorption Rate (SAR) certification information

Your phone conforms to European Union (EU) standards that limit human exposure to radio frequency (RF) energy emitted by radio and telecommunications equipment. These standards prevent the sale of mobile phones that exceed a maximum exposure level (known as the Specific Absorption Rate, or SAR) of 2.0 W/kg.

During testing, the maximum SAR recorded for this model was 0.644 W/kg. In normal use, the actual SAR is likely to be much lower, as the phone has been designed to emit only the RF energy necessary to transmit a signal to the nearest base station. By automatically emitting lower levels when possible, your phone reduces your overall exposure to RF energy.

For more information about the SAR and related EU standards, visit the Samsung mobile phone website.

Correct disposal of this product

(Waste Electrical & Electronic Equipment)



(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Correct disposal of batteries in this product



(Applicable in the European Union and other European countries with separate battery return systems)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

Disclaimer

Some content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal noncommercial use. You may not use any content or services in a manner that has not been authorised by the content owner or service provider. Without limiting the foregoing, unless expressly authorised by the applicable content owner or service provider, you may not modify, copy, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium any content or services displayed through this device.

"THIRD PARTY CONTENT AND SERVICES ARE PROVIDED "AS IS." SAMSUNG DOES NOT WARRANT CONTENT OR SERVICES SO PROVIDED, EITHER EXPRESSLY OR IMPLIEDLY,

FOR ANY PURPOSE. SAMSUNG EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SAMSUNG DOES NOT GUARANTEE THE ACCURACY, VALIDITY, TIMELINESS, LEGALITY, OR COMPLETENESS OF ANY CONTENT OR SERVICE MADE AVAILABLE THROUGH THIS DEVICE AND UNDER NO CIRCUMSTANCES, INCLUDING NEGLIGENCE, SHALL SAMSUNG BE LIABLE, WHETHER IN CONTRACT OR TORT, FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, ATTORNEY FEES, EXPENSES, OR ANY OTHER DAMAGES ARISING OUT OF, OR IN CONNECTION WITH, ANY INFORMATION CONTAINED IN, OR AS A RESULT OF THE USE OF ANY CONTENT OR SERVICE BY YOU OR ANY THIRD PARTY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES."

Third party services may be terminated or interrupted at any time, and Samsung makes no representation or warranty that any content or service will remain available for any period of time. Content and services are transmitted by third parties by means of networks and transmission facilities over which Samsung has no control. Without limiting the generality of this disclaimer, Samsung expressly disclaims any responsibility or liability for any interruption or suspension of any content or service made available through this device.

Samsung is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services should be made directly to the respective content and service providers.

introducing your mobile phone

In this section, learn about your mobile phone's layout, keys, and icons.

Unpack

Check your product box for the following items:


- Mobile phone
- Battery
- Travel adapter (charger)
- User manual




- The items supplied with your phone may vary depending on the software and accessories available in your region or offered by your service provider. You can obtain additional accessories from your local Samsung dealer.
- The supplied accessories perform best for your phone.

Phone layout

The front of your phone includes the following keys and features:



The rear of your phone includes the following keys and features:



You can lock the touch screen and keys to prevent any unwanted phone operations. To lock, press [A]. To unlock, press and hold [A].

Keypad


Key	Function
 Dial	Make or answer a call; In Idle mode, retrieve recently dialed, missed, or received numbers
 Back	Return to the previous level
 Power/ Menu exit	Turn the phone on and off (press and hold); End a call; In Menu mode, cancel input and return to Idle mode
 Volume	Adjust the phone's volume
 Hold	Lock the touch screen and keys; Unlock the touch screen and keys (press and hold)
 Camera	In Idle mode, turn on the camera (press and hold); In Camera mode, take a photo or record a video

Icons

Learn about the icons that appear on your display.

Icon	Definition
	Signal strength
	GPRS network connected
	EDGE network connected
	Call in progress
	SOS message feature activated
	Connecting to secured web page
	Call diverting activated
	Synchronised with PC
	Roaming (outside of normal service area)
	Bluetooth activated
	Music playback in progress
	Music playback paused

Icon	Definition
	FM radio on
	Memory card inserted
	New text message
	New multimedia message
	New email message
	New voice mail message
	Alarm activated
	Normal profile activated
	Silent profile activated
	Battery power level
	Current time



assembling and preparing your mobile phone


Get started by assembling and setting up
your mobile phone for its first use.

Install the SIM card and battery

When you subscribe to a cellular service, you will receive a Subscriber Identity Module (SIM) card with subscription details, such as your personal identification number (PIN) and optional services.


To install the SIM card and battery,

1. Remove the battery cover.




If the phone is on, press and hold [⏻] to turn it off.

2. Insert the SIM card.




- Place the SIM card in the phone with the gold-coloured contacts facing down.
- Without inserting a SIM card, you can use your phone's non-network services and some menus.

3. Insert the battery.




4. Replace the battery cover.



Charge the battery

Before using the phone for the first time, you must charge the battery.

1. Open the cover to the multifunction jack on the side of the phone.
2. Plug the small end of the travel adapter into the multifunction jack.



With the triangle facing up



CAUTION

Improperly connecting the travel adapter can cause serious damage to the phone. Any damages by misuse are not covered by the warranty.

3. Plug the large end of the travel adapter into a power outlet.
4. When the battery is fully charged (the  icon is no longer moving), unplug the travel adapter from the power outlet.
5. Unplug the travel adapter from the phone.
6. Close the cover to the multifunction jack.



About the low battery indicator

When your battery is low, the phone will emit a warning tone and a low battery message. The battery icon will also be empty and blinking. If the battery level becomes too low, the phone will automatically power off. Recharge your battery to continue using your phone.

Insert a memory card (optional)

To store additional multimedia files, you must insert a memory card. Your phone accepts microSD™ or microSDHC™ memory cards up to 8 GB (depending on memory card manufacturer and type).



Formatting the memory card on a PC may cause incompatibility with your phone. Format the memory card only on the phone.

1. Open the cover to the memory card slot on the side of the phone.
2. Insert a memory card with the label side facing down.



3. Push the memory card in the memory card slot until it locks in place.

Push it gently until it disengages from the phone, and then pull the memory card out of the memory card slot.

Attach a hand strap (optional)

1. Remove the battery cover.
2. Slide a hand strap through the slot and hook it over the small projection.



3. Replace the battery cover.

using basic functions

Learn how to perform basic operations and use the main features of your mobile phone.

Turn your phone on and off

To turn your phone on,

1. Press and hold [].
2. Enter your PIN and select **Done** (if necessary).

To turn your phone off, repeat step 1 above.

Switch to the offline profile

By switching to the offline profile, you can use your phone's non-network services in areas where wireless devices are prohibited, such as aeroplanes and hospitals.

To switch to the offline profile, in Menu mode, select **Settings** → **Phone profiles** → **Offline** → **Save**.



Follow all posted warnings and directions from official personnel when in areas where wireless devices are prohibited.

Use the touch screen

Your phone's touch screen lets you easily select items or perform functions. Learn basic actions to use the touch screen.




CAUTION


- To avoid scratching the touch screen, do not use sharp tools.
- Do not allow the touch screen to come in contact with other electrical devices. Electrostatic discharges can cause the touch screen to malfunction.
- Do not allow the touch screen to come in contact with water. The touch screen may malfunction in humid conditions or when exposed to water.




- For the optimal use of the touch screen, remove the screen protection film before using your phone.
- Your touch screen has a layer that detects small electrical charges emitted by the human body. For best performance, tap the touch screen with your fingertip. The touch screen will not react to touches of sharp tools, such as a stylus or pen.
- Touch an icon to open a menu or launch an application.



- Drag your finger up or down to scroll through vertical lists.



- Drag your finger left or right to scroll through horizontal lists.



Access menus

To access your phone's menus,

1. In Idle mode, select **Menu** to access Menu mode.
2. Select a menu or option.
3. Press the Back key to move up one level; Press [] to return to Idle mode.

Use widgets

Learn to use widgets on the widget toolbar.



- Some of your widgets connect to web services. Selecting a web-based widget may incur additional charges.
- Available widgets may vary depending on your region or service provider.

Open the widget toolbar

In Idle mode, select the arrow at the bottom left of the screen to open the widget toolbar. You can rearrange widgets on the widget toolbar or move them to the idle screen.

Move the widgets to the idle screen

1. Open the widget toolbar.
2. Drag a widget from the widget toolbar to the idle screen. You can position the widget anywhere on the screen.



To move the widgets from the idle screen to the widget toolbar back, select and drag a widget to the widget toolbar.

Change the widgets

1. Open the widget toolbar.
2. Select  from the widget toolbar.
3. Select the widgets you want to include to the widget toolbar and select **Save**.

Customise your phone

Get more from your phone by customising it to match your preferences.

Adjust the volume of the key tones

In Idle mode, press the Volume key and adjust the key tone volume.

Adjust the vibration intensity on the touch screen

You can adjust the intensity of the vibration when you touch the phone screen.

1. In Idle mode, press the Volume key.
2. Select **Vibration** and adjust the intensity of the vibration.

Switch to or from the silent profile

In Idle mode, select **Keypad** and touch and hold **#** to silence or unsilence your phone.

Set a phone profile

To change the ringtone of the current profile,

1. In Menu mode, select **Settings** → **Phone profiles**.
2. Scroll to the profile you are using.



If you are using the silent or offline profile, you are not allowed to change the ringtone.

3. Select **Edit** → **Voice call ringtone**.
4. Select a ringtone category → a ringtone.
5. Select **Save** or **Set** → **Save**.

To switch to another profile, select it from the list and select **Save**.

To create a phone profile,

1. In Menu mode, select **Settings** → **Phone profiles**.
2. Select **Create**.
3. Enter a name for the profile and select **Done**.
4. Customise the sound settings as desired.
5. When you are finished, select **Save**.

Select a wallpaper (Idle mode)

1. In Menu mode, select **Settings** → **Display and light** → **Wallpaper**.
2. Scroll left or right to an image.
3. Select **Set**.

Select a theme for the display

1. In Menu mode, select **Settings** → **Display and light** → **My theme**.
2. Select a theme and select **Save**.

Lock your phone

1. In Menu mode, select **Settings** → **Security** → **Phone lock** → **On** → **Save**.
2. Enter a new 4- to 8-digit password and select **Done**.

3. Enter the new password again and select **Done**.



- The first time you access a menu that requires a password, you will be prompted to create and confirm a password.
- Samsung is not responsible for any loss of passwords or private information or other damages caused by illegal software.

Use basic call functions

Learn to make or answer calls and use basic call functions.

Make a call

1. In Idle mode, select **Keypad** and enter an area code and a phone number.
2. Press [] to dial the number
3. To end the call, press [.

Answer a call

1. When a call comes in, press [.
2. To end the call, press [.

Adjust the volume

To adjust the volume during a call, press the Volume key.

Record a call conversation

1. During a call, select **More** → **Record call** to start recording.
2. When you are finished, select **Save**.

Use the speakerphone feature

1. During a call, select  → **Yes** to activate the speaker.

2. To switch back to the earpiece, select  again.



In noisy environments, you may have difficulty hearing the calls while using the speakerphone feature. For better audio performance, use the normal phone mode.

Use the headset

By plugging the supplied headset into the phone's multifunction jack, you can make and answer calls:

- To redial the last call, press and hold the headset button.
- To answer a call, press the headset button.
- To end a call, press and hold the headset button.

Send and view messages

Learn to send or view text (SMS), multimedia (MMS), or email messages.

Send a text or multimedia message

1. In Menu mode, select **Messages** → **Create new message** → **Message**.
2. Select **Tap to add recipient** → **Enter manually**.
3. Enter a recipient number and select **Done**.
4. Select **Tap to add text**.
5. Enter your message text and select **Done**.
▶ p. 27
For sending as a text message, skip to step 7.
For attaching multimedia, continue with step 6.
6. Select **Add multimedia** and add an item.
7. Select **Send** to send the message.

Send an email

1. In Menu mode, select **Messages** → **Create new message** → **Email**.
2. Select **Tap to add recipient** → **Enter manually**.

3. Enter an email address and select **Done**.
4. Select **Tap to add subject**.
5. Enter a subject and select **Done**.
6. Select **Tap to add text**.
7. Enter your email text and select **Done**.
8. Select **Attach multimedia** and attach a file (if necessary).
9. Select **Send** to send the message.

Enter text

With your phone's touch screen, you can enter text and create messages or notes.

When entering text, you can change the text input mode:

- Select **T9** to switch between T9 and ABC modes. Depending on your region, you may be able to access an input mode for your specific language.

- Select **Abc** or **T9Ab** to change case or switch to Number mode.
- Select  to switch to Symbol mode.
- Select **EN** to change the input language.

You can use the following text input modes:

Mode	Function
ABC	Select an appropriate virtual key until the character you want appears on the display.
T9	1. Select appropriate virtual keys to enter an entire word. 2. When the word displays correctly, select  to insert a space. If the correct word does not display, select  to select an alternate word.
Number	Select an appropriate virtual key to enter a number.
Symbol	Select an appropriate virtual key to enter a symbol.

View text or multimedia messages

1. In Menu mode, select **Messages** → **My messages** → **Inbox**.
2. Select a text or multimedia message.

You can view all text or multimedia messages sent to and received from a specific contact like a messenger.

1. In Menu mode, select **Messages** → **Conversations**.
2. Select a contact.

View an email

1. In Menu mode, select **Messages** → **My messages** → **Email inbox**.
2. Select an account.
3. Select **Download**.

4. Select an email or a header.
5. If you selected a header, select **Retrieve** to view the body of the email.

Add and find contacts

Learn the basics of using the phonebook feature.



The memory location to save new contacts may be preset depending on your service provider. To change the memory location, in Menu mode, select **Phonebook** → **More** → **Settings** → **Save new contacts to** → a memory location.

Add a new contact

1. In Idle mode, select **Keypad** and enter a phone number.
2. Select **More** → **Add to Phonebook** → a memory location (if necessary) → **New**.

3. Select a number type (if necessary).
4. Enter contact information.
5. Select **Save** to add the contact to memory.

Find a contact

1. In Menu mode, select **Phonebook**.
2. Select **Search**.
3. Enter the first few letters of the name you want to find and select **Done**.
4. Select the contact's name from the search list.



Once you have found a contact, you can:

- call the contact by pressing [**↩**]
- edit the contact information by selecting **Edit**.

Use basic camera functions

Learn the basics to capture and view photos and videos.

Capture photos

1. In Idle mode, press and hold [] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Aim the lens at the subject and make any adjustments.
 - To set the exposure value, select .
 - To zoom in or out, press the Volume key.
4. Press [] to take a photo.
The photo is saved automatically.
5. Press the Back key or [] to take another photo (step 3).

After capturing photos, select  to view photos.

View photos

In Menu mode, select **My files** → **Images** → **My photos** → a photo file.

While viewing photos, select  →  or  to zoom in or out. Press the Back key to exit the zoom screen.

Capture videos

1. In Idle mode, press and hold [] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select  →  to switch to Recording mode.
4. Aim the lens at the subject and make any adjustments.
 - To set the exposure value, select .
 - To zoom in or out, press the Volume key.

5. Press [>] to start recording.
 6. Press [>] or select  to stop recording.
The video is saved automatically.
 7. Press the Back key or [>] to record another video (step 4).
- After capturing videos, select  to view videos.

View videos

In Menu mode, select **My files** → **Videos** → **My video clips** → a video file.



Your phone can play 320 X 240 resolution video files at 12 frames per second.

Listen to music

Learn how to listen to music via the music player or FM radio.

Listen to the FM radio

1. Plug the supplied headset into the phone.
2. In Menu mode, select **FM radio**.
3. Select  to turn on the FM radio.
4. Select **Yes** to start automatic tuning.
The radio scans and saves available stations automatically.



The first time you turn on the FM radio, you will be prompted to start automatic tuning.

5. Control the FM radio using the following icons and keys:

Icon	Function
<< >>	Tune a radio station manually; Tune a radio station automatically (touch and hold)
▶	Turn the FM radio on
■	Turn the FM radio off
🎧 / 🔊	Change the sound output
⋮	Open the favourite list ▶ p. 47
AF / 	Set the FM radio to retune frequencies for stations automatically when the current radio signal is weak

Listen to music files

Start by transferring files to your phone or memory card:

- Download from the wireless web. ▶ p. 33
- Download from a PC with the optional Samsung PC Studio. ▶ p. 45
- Receive via Bluetooth. ▶ p. 49
- Copy to your memory card. ▶ p. 45

After transferring music files to your phone or memory card,

1. In Menu mode, select **Music**.
2. Select a music category → a music file.
3. Control playback using the following icons and keys:

Icon/Key	Function
⏸	Pause playback

Icon/Key	Function
	Resume playback
	Restart playback; Skip backward (select within 3 seconds); Scan backward in a file (touch and hold)
	Skip forward; Scan forward in a file (touch and hold)
NORM ¹	Change the sound effect
	Change the repeat mode
	Activate the Shuffle mode

1. When you touch the screen, the icons will be available.



If you select **My files** → a music file, you cannot skip forward or backward during playback.

Browse the web

Learn to access and bookmark your favourite web pages.



- You may incur additional charges for accessing the web and downloading media.
- The browser menu may be labelled differently depending on your service provider.
- Available icons may vary depending on your region or service provider.

Browse web pages

1. In Menu mode, select **Internet** → **Home** to launch your service provider's homepage.
2. Navigate web pages using the following icons:

Icon	Function
	Move backward or forward on a web page
	Stop loading the web page

Icon	Function
	Refresh the current web page
	Zoom on a web page
	Change the view mode
	Access a list of browser options

Bookmark your favourite web pages

1. In Menu mode, select **Internet** → **Bookmarks**.
2. Select **Create**. If there are bookmarks saved, select **Options** → **Add bookmark**.
3. Enter a page title and a web address (URL).
4. Select **Save**.

Download media files



This feature may be unavailable depending on your region or service provider.

1. In Menu mode, select **Samsung Apps** or **Downloads**.
2. Search for a ringtone or picture and download it to the phone.

Use the Google services

Learn how to use various Google services.



- This feature may be unavailable depending on your region or service provider.
- The steps you must select to use this feature may differ depending on your region or service provider.

Connect to Search

1. In Menu mode, select **Google** → **Search**.
2. Enter a keyword in the search field.

Connect to Mail

1. In Menu mode, select **Google** → **Mail**.
2. Set up your Google account and sign in.
3. Send or receive emails.



using advanced functions

Learn how to perform advanced operations and use additional features of your mobile phone.

Use advanced call functions

Learn about your phone's additional calling capabilities.

View and dial missed calls

Your phone will display calls you have missed on the display. To dial the number of a missed call,

1. Select the call from the event alert widget and select **View**.
2. Scroll to the missed call you want to dial.
3. Press [] to dial.

Call a recently dialled number

1. In Idle mode, press [] to display a list of recent numbers.
2. Select the number you want and press [] to dial.

Hold a call or retrieve a held call

Select  to place a call on hold or select  to retrieve a held call.

Dial a second call

If your network supports this function, you can dial another number during a call:

1. Select  to place the first call on hold.
2. Select **Keypad** and enter the second number to dial, and then press [].
3. Select  to switch between the two calls.
4. To end the call on hold, select **More** → **End** → **Held call**.
5. To end the current call, press [].

Answer a second call

If your network supports this function, you can answer a second incoming call:

1. Press [] → **Hold active call** to answer the second call.
The first call is automatically placed on hold.
2. Select  to switch between the calls.

Make a multiparty call (conference call)

1. Call the first party you want to add to the multiparty call.
2. While connected to the first party, call the second party.
The first party is automatically placed on hold.
3. When connected to the second party, select **More** → **Conference call**.

4. Repeat steps 2 and 3 to add more parties (if necessary).
5. To end the multiparty call, press [].

Call an international number

1. In Idle mode, select **Keypad** and touch and hold **0** to insert the **+** character.
2. Enter the complete number you want to dial (country code, area code, and phone number), and then press [] to dial.

Call a contact from the phonebook

You can call numbers directly from the phonebook using stored contacts. ► p. 29

1. In Menu mode, select **Phonebook**.
2. Select the number you want to dial and press [] to dial.

Reject a call

To reject an incoming call, press []. The caller will hear a busy tone.

To reject calls from certain numbers automatically, use the auto rejection. To activate the auto rejection and set up the reject list,

1. In Menu mode, select **Settings** → **Application settings** → **Call** → **All calls** → **Auto reject**.
2. Select **On** under **Activation**.
3. Select **Reject list**.
4. Select **Create**.
5. Select the number input field.
6. Enter a number to reject and select **Done**.
7. Select **Match criteria** → an option → **Select**.
8. Select **Save**.
9. Repeat steps 4-8 to add more numbers.
10. Select **Save** twice.

Use advanced phonebook functions

Learn to create your namecard, set speed dial numbers, and create groups of contacts.

Create your namecard

1. In Menu mode, select **Phonebook**.
2. Select **More** → **My namecard**.
3. Enter your personal details.
4. Select **Save**.



You can send your namecard by attaching it to a message or email or transferring it via the Bluetooth wireless feature.

Set speed dial numbers

1. In Menu mode, select **Phonebook**.
2. Select a contact to assign.
3. Select **More** → **Add to speed dial**.

4. Select a number (if necessary).
5. Select a speed dial number you want to set.
The contact is saved to the speed dial number.



- You can call this contact by touching and holding the assigned speed dial number in the dialling screen.
- The first 3 speed dial numbers will be assigned to the top 3 list () on the widget toolbar.

Create a group of contacts

By creating groups of contacts, you can assign ringtones and caller ID photos to each group or send messages to an entire group. Start by creating a group:

1. In Menu mode, select **Phonebook**.
2. Scroll left or right to **Groups**.
3. Select **Create**.

4. Enter a group name and select **Done**.
5. To set the caller ID image, select the new group → **Group settings** → the image field → an image category → an image → **Set**.
6. To set a group ringtone, select the ringtone field → a ringtone category → a ringtone → **Set** or **Select**.
7. Select **Save**.

Use advanced messaging functions

Learn to create templates, use templates to create new messages, and use the messengers.

Create a text template

1. In Menu mode, select **Messages** → **Templates** → **Text templates**.
2. Select **Create** to open a new template window.
3. Enter your text and select **Done**.

Create a multimedia template

1. In Menu mode, select **Messages** → **Templates** → **Multimedia message templates**.
2. Select **Create** to open a new template window.
3. Create a multimedia message, with a subject and desired attachments, to use as your template. ► p. 27
4. Select **More** → **Save to** → **Templates**.

Insert text templates in new messages

1. In Menu mode, select **Messages** → **Create new message** → a message type.
2. In the text field, select **More** → **Insert** → **Template** → a template.

Create a message from a multimedia template

1. In Menu mode, select **Messages** → **Templates** → **Multimedia message templates**.
2. Select the template you want.
3. Select **More** → **Edit**.
Your template opens as a new multimedia message.

Use the Bluetooth messenger

Learn to chat with your family or friends instantly via the Bluetooth wireless feature.

1. In Menu mode, select **Messages** → **Bluetooth messenger**.
2. Select **Yes** to turn on the Bluetooth wireless feature.
3. Select **Search**.

4. Select a device.
5. Select the message input field.
6. Enter your message and select **Done**.
7. Select **Send**.
8. Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and select **OK**.
When the owner of the other device enters the same PIN or accepts the connection, pairing is complete.



You may not need to enter a PIN depending on the device.

Use the Palringo messenger

Learn to chat with your family or friends.

1. In Menu mode, select **Messenger**.
2. Select **OK** from the intro window.



The first time you access **Palringo**, you will be prompted to confirm.

3. Select **Menu** → **Sign In**.
4. Enter a user name and password and select **Sign In**.
When you are signed in to the messenger, the contact list shows all of your messenger contacts.
5. Select a contact you want to chat with. The chat screen opens.
6. Enter and send your message.

Use advanced camera functions

Learn how to capture photos in various modes and customise camera settings.

Capture a series of photos

1. In Idle mode, press and hold [] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select → **Shooting mode** → **Multi-shot**.
4. Make any necessary adjustments.
5. Press and hold [] to take a series of photos.

Capture divided photos

1. In Idle mode, press and hold [] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select  → **Shooting mode** → **Mosaic shot**.
4. Select an image layout.
5. Make any necessary adjustments.
6. Press [] to take photos for each segment.

Capture photos with decorative frames

1. In Idle mode, press and hold [] to turn on the camera.
2. Rotate the phone anti-clockwise to landscape view.
3. Select  → **Shooting mode** → **Frame shot**.
4. Select a frame.

5. Make any necessary adjustments.
6. Press [] to take a photo with the frame.

Use camera options

Before capturing a photo, select  to access the following options:

Option	Function
Shooting mode	Change the shooting mode
Resolution	Change the resolution option
Timer	Select the time delay
White balance	Adjust the colour balance
Effects	Apply a special effect
Viewfinder mode	Change the preview screen
More settings	Change the camera settings

Before capturing a photo, select  → **More settings** to access the following settings:

Setting	Function
Quality	Adjust the quality of your photos
Exposure metering	Select a type of exposure metre
Single shot mode	Adjust how the camera saves captured photos
Shutter sound	Select a sound to accompany the shutter action
Night mode	Set whether to use Night mode
Default storage	Select a memory location to store new photos
Default name	Edit a default name for new photos

Before capturing a video, select  to access the following options:

Option	Function
Recording mode	Change the recording mode
Resolution	Change the resolution option
Timer	Select the time delay
White balance	Adjust the colour balance
Effects	Apply a special effect
Audio recording	Turn the audio on or off
Viewfinder mode	Change the preview screen
Quality	Set the quality of your video clips
Default storage	Select a memory location to store new video clips
Default name	Edit a default name for new video clips

Use advanced music functions

Learn to prepare music files, create playlists, and store radio stations.

Copy music files via Samsung PC Studio

1. In Menu mode, select **Settings** → **PC connections** → **Samsung PC studio** or **Mass storage** → **Save**.
2. Using an optional PC data cable, connect the multifunction jack on your phone to a PC.
3. Run Samsung PC Studio and copy files from the PC to the phone.
Refer to the Samsung PC Studio help for more information.

Copy music files to a memory card

1. Insert a memory card (if necessary).
2. In Menu mode, select **Settings** → **PC connections** → **Mass storage** → **Save**.
3. Using an optional PC data cable, connect the multifunction jack on your phone to a PC.
When connected, a pop-up window will appear on the PC.
4. Open a folder to view files.
5. Copy files from the PC to the memory card.

Create a playlist

1. In Menu mode, select **Music** → **Playlists**.
2. Select **Create**.
3. Enter a title for your new playlist and select **Done**.
4. Select the new playlist.

5. Select **Add** → **Tracks**.
6. Select the files you want to include and select **Add**.

Customise your music player settings

1. In Menu mode, select **Music**.
2. Select **Settings**.
3. Adjust the settings to customise your music player:

Option	Function
Background playing	Set whether to play music in the background when you end the music player
Music auto off	Set the timer when the music player automatically turns off

4. Select **Save**.

Record songs from the FM radio

1. Plug the supplied headset into the phone.
2. In Menu mode, select **FM radio**.
3. Select ► to start the FM radio.
4. Select **More** → **Record** to start recording.
5. When you are finished recording, select **Stop**.
The music file will be saved in **FM radio clips** (in Menu mode, select **My files** → **Music**).



The recording feature is developed for voice recording only. The quality of the recording will be much lower than digital media.

Store radio stations automatically

1. Plug the supplied headset into the phone.
2. In Menu mode, select **FM radio**.
3. Select ► to start the FM radio.
4. Select **More** → **Self-tuning**.
5. Select **Yes** to confirm (if necessary).
The radio scans and saves available stations automatically.

Set up your favourite radio station list

1. Plug the supplied headset into the phone.
2. In Menu mode, select **FM radio**.
3. Select ► to start the FM radio.
4. Select a radio station to add the favourite list.
5. Select **Add to Favourites**.



using tools and applications

Learn how to work with your mobile phone's tools and additional applications.

Use the Bluetooth wireless feature

Learn about your phone's ability to connect to other wireless devices for exchanging data and using hands-free features.

Turn on the Bluetooth wireless feature

1. In Menu mode, select **Bluetooth** → **Activation** → **On** → **Save**.
2. To allow other devices to locate your phone, select **My phone's visibility** → **On** → **Save**.

Find and pair with other Bluetooth-enabled devices

1. In Menu mode, select **Bluetooth** → **My devices** → **Search new device**.
2. Select a device.

3. Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and select **Done**.

When the owner of the other device enters the same PIN or accepts the connection, pairing is complete.



You may not need to enter a PIN depending on the device.

Send data using the Bluetooth wireless feature

1. Select the file or item from one of your phone's applications that you want to send.
2. Select **Send via** → **Bluetooth** or select **More** → **Send namecard via** → **Bluetooth** (when sending contact data, specify which data to send).

Receive data using the Bluetooth wireless feature

1. Enter the PIN for the Bluetooth wireless feature and select **Done** (if necessary).
2. Select **Yes** to confirm that you are willing to receive data from the device (if necessary).

Use Remote SIM mode

In Remote SIM mode, you can make or answer calls only with a connected Bluetooth hands-free car kit via the SIM card on your phone.

To activate Remote SIM mode,

1. In Menu mode, select **Bluetooth** → **Remote SIM mode**.
2. Select **On** → **Save**.

To use Remote SIM mode, start the Bluetooth connection from a Bluetooth hands-free car kit.



The Bluetooth hands-free car kit must be authorised. To authorise, select the device and select **More** → **Authorise device**.

Activate and send an SOS message

When you have an emergency, you can send an SOS message asking for help.

1. In Menu mode, select **Messages** → **SOS messages** → **Sending options**.
2. Select **On** to turn on the SOS messaging feature.
3. Select **Empty** under **Recipients** to open the recipient list.
4. Select **Add recipients** → **Phonebook** to open your contact list.

5. Select the contacts you want.
6. Select a number (if necessary).
7. When you are finished selecting contacts, select **Add** to return to the recipient list.
8. Select **Save** to save the recipients.
9. Select **Once** under **Repeats** and set the number of times to repeat the SOS message.
10. Select **Save** → **Yes**.

To send an SOS message, the touch screen and keys must be locked. Press the Volume key four times.



Once you send an SOS message, all phone functions will be suspended until you press and hold [**⏏**].

Use the mobile tracker 2.0

When someone inserts a new SIM card in your phone, the mobile tracker feature will automatically send the contact number to two recipients to help you locate and recover your phone.

Activate the mobile tracker 2.0

1. In Menu mode, select **Settings** → **Security** → **Mobile tracker 2.0**.
2. Select **OK** to set a phone password.
3. Enter your phone password and select **Done**.



The first time you access a menu that requires a password, you will be prompted to create and confirm a password.

4. Select **Settings**.

5. Enter the password for the mobile tracker (8 digits) and select **Done**.
6. Select **On** to turn on the mobile tracker.
7. Select **Empty** under **Recipients** to open the recipient list.
8. Select **Add recipients** → **Phonebook** to open your contact list.
9. Select the contacts you want.
10. Select a number (if necessary).
11. When you are finished selecting contacts, select **Add** to return to the recipient list.
12. Select **Save** to save the recipients.
13. Select the sender input field.
14. Enter the sender's name and select **Done**.
15. Select **Save** → **Save** → **Accept**.

Access a remote phone

If a remote phone has the mobile tracker 2.0 feature and it is activated, you can delete data, forward calls, and get contact or location information of the remote phone.

To get contact information of the remote phone,

1. In Menu mode, select **Settings** → **Security** → **Mobile tracker 2.0** → **Access remote phone**.
2. Enter the phone number of the remote phone and select **Done**.
3. Enter the mobile tracker password of the remote phone and select **Done**.
4. Select **OK**.
5. Select **Get contact**.
6. Enter the contact name on the remote phone and select **Done**.
7. Select **Send**.

To delete data on the remote phone,

1. From the Access remote phone screen, select **Delete user data**.
2. Select **Yes**.
A call log list, contacts, and all messages of the remote phone will be deleted.

To forward calls to another phone,

1. From the Access remote phone screen, select **Set call diverting**.
2. Enter the phone number to which incoming calls of the remote phone will be forwarded and select **Done**.
3. Select **Options** → **Activate**.
All incoming calls of the remote phone will be forwarded to the new phone number.

To get location information,

1. From the Access remote phone screen, select **Get location information**.
2. Select **Send**.

An SMS message that contains the location information will come in.



To change the password for the mobile tracker, select **Change Mobile tracker 2.0 password**.

Make fake calls

You can simulate an incoming call when you want to get out of meetings or unwanted conversations. You can also make it appear as if you are talking on the phone by playing back a recorded voice.

Activate the fake call feature

1. In Menu mode, select **Settings** → **Application settings** → **Call** → **Fake call**.
2. Select **On** under **Activation**.

Make a fake call

In Idle mode, press and hold the Volume key down.

Record a voice

1. In Menu mode, select **Settings** → **Application settings** → **Call** → **Fake call** → **Fake call voice**.
2. Select **On** under **Fake call voice**.
3. Select **Voice recording**.
4. Select ● to start recording.
5. Speak into the microphone.

- When you are finished speaking, select .
- Select **Back** → **Save** to set the recording as a response for fake calls.

Change the time delay before fake calls

- In Menu mode, select **Settings** → **Application settings** → **Call** → **Fake call** → **Fake call timer**.
- Select an option → **Save**.

Record and play voice memos

Learn to operate your phone's voice recorder.

Record a voice memo

- In Menu mode, select **Voice recorder**.
- Select  to start recording.
- Speak your memo into the microphone.
- When you are finished speaking, select  or **Save**.

Play a voice memo

- In Menu mode, select **Voice recorder** → **My voice clips**.
- Select a file.
Press the Volume key up or down to adjust the volume during playback.

Edit images

Learn to edit images and apply fun effects.

Apply effects to images

- In Menu mode, select **Image editor**.
- Select **Files** → **Open** or **Take photo**.
- Select an image or take a new photo → **Load**.
- Press  → an effect option (filter, style, warp, or partial blur).

5. Select a variation of the effect to apply and select **Done**.
To apply a blur effect to a specific area of an image, draw the rectangle and select **Done**.
6. When you are finished, select **Files** → **Save as**.
7. Enter a new file name for the image and select **Save**.

Transform an image

1. Open an image to be edited. Refer to steps 1-3 in "Apply effects to images."
2. Select  → **Resize, Rotate, or Flip**.
3. Rotate or flip the image as desired and select **Done**.
To resize the image, select a size → **Select** → **Yes**, and skip to step 5.
4. Save the edited image with a new file name.
Refer to steps 6-7 in "Apply effects to images."

Crop an image

1. Open an image to be edited. Refer to steps 1-3 in "Apply effects to images."
2. Select .
3. Draw the rectangle over the area you want to crop and select **Done**.
To reshape the rectangle, select **Shape**.
4. Save the edited image with a new file name.
Refer to steps 6-7 in "Apply effects to images."

Adjust an image

1. Open an image to be edited, Refer to steps 1-3 in "Apply effects to images."
2. Select  → an adjustment option (brightness, contrast, or colour).
To adjust the image automatically, select **Auto level**.

3. Adjust the image as desired and select **Done**.
4. Save the edited image with a new file name.
Refer to steps 6-7 in "Apply effects to images."

Insert a visual feature

1. Open an image to be edited. Refer to steps 1-3 in "Apply effects to images."
2. Select **More** → **Insert** → a visual feature (frame, image, clip art, emoticon, or text).
3. Select a visual feature, or enter text and select **Save**.
4. Move or resize the visual feature or text and select **Done**.
5. Save the edited image with a new file name.
Refer to steps 6-7 in "Apply effects to images."

Print images

Learn to print your image with a USB connection or the Bluetooth wireless feature.

To print an image using a USB connection,

1. In Menu mode, select **Settings** → **PC connections** → **Printer** → **Save**.
2. Connect the multifunction jack on your phone to a compatible printer.
3. Open an image. ► p. 30
4. Select **More** → **Print via** → **USB**.
5. Set print options and print the image.

To print an image using the Bluetooth wireless feature,

1. Open an image. ► p. 30
2. Select **More** → **Print via** → **Bluetooth** → **Print**.

3. Select a Bluetooth-enabled printer and pair with the printer. ► p. 48
4. Set print options and print the image.

View photos and videos on the web

Learn to access photo sharing websites and blogs and view photos and videos.



This feature may be unavailable depending on your region or service provider.

1. In Menu mode, select **Communities**.
2. Select a website or blog you want to view.
3. Enter your user ID and password of the destination (if necessary).

Use Java-powered games and applications

Learn to use games and applications powered by award-winning Java technology.



The download of Java files or Java applications may not be supported depending on the software of the phone.

Download games or applications

1. In Menu mode, select **Games and more** → **More games**.
Your phone connects to the website preset by your service provider.
2. Search for a game or an application and download it to the phone.



This feature may be unavailable depending on your region or service provider.

Play games

1. In Menu mode, select **Games and more**.
2. Select a game from the list and follow the on-screen instructions.



Available games may vary, depending on your region or service provider. Game controls and options may vary.

Launch applications

1. In Menu mode, select **Games and more** → an application.
2. Select **More** to access a list of various options and settings for your application.

Synchronise data

Learn to synchronise the contacts, calendar events, and tasks with the web server you have specified.

To create a synchronisation profile,

1. In Menu mode, select **Synchronise**.
2. Select **Add** and specify profile parameters.
3. When you are finished, select **Save**.

To start synchronisation,

1. In Menu mode, select **Synchronise**.
2. Select a synchronisation profile.
3. Select **OK** to start synchronisation with the web server you have specified.

Create and view world clocks

Learn to view the time in another region and set world clocks to appear on your display.

Create a world clock

1. In Menu mode, select **World clock**.
2. Select **Add**.
3. Scroll left or right to a time zone.
4. To set daylight saving time, select .
5. Select **Add** to create your world clock.
The world clock is set as the second clock.
6. Select **Add** to add more world clocks (step 3).

Add a world clock to your display

With the dual clock widget, you can view clocks with two different time zones on your display.

After you have created a world clock,

1. In Menu mode, select **World clock**.
2. Scroll to the world clock you want to add and select **More** → **Set as 2nd clock**.

Set and use alarms

Learn to set and control alarms for important events.

Set a new alarm

1. In Menu mode, select **Alarms**.
2. Select an empty alarm location or select **Create**.
3. Set alarm details.
4. Select **Save**.



The auto power-up feature sets the phone to automatically turn on and sound the alarm at the designated time if the phone is turned off.

Stop an alarm

When the alarm sounds,

- Select **OK** to stop the alarm without snooze.
- Select **OK** to stop the alarm with snooze, or select **Snooze** to silence the alarm for the snooze period.

Deactivate an alarm

1. In Menu mode, select **Alarms**.
2. Select the alarm you want to deactivate.
3. Select **Off** under **Alarm**.
4. Select **Save**.

Use the mobile prayer feature

The mobile prayer feature alerts you to prayer time using a specified alarm tone and wallpaper. You can set different alarms for each day.

1. In Menu mode, select **Mobile prayer**.
2. Select your religion to customise the mobile prayer settings.
If you select **Islamic salat**, select a prayer type.
3. Select a day you want.
4. Scroll left or right to **On**.
5. Set details as desired and select **Save**.

Use the calculator

1. In Menu mode, select **Calculator**.
2. Use the keys that correspond to the calculator display to perform basic mathematical operations.

Convert currencies or measurements

1. In Menu mode, select **Convertor** → a conversion type.
2. Enter the currencies or measurements and units in the appropriate fields.

Set a countdown timer

1. In Menu mode, select **Timer**.
2. Select **Set**.
3. Enter the length of time to count down and select **Done**.
4. Select **Play** to begin or pause the countdown.
5. When the timer expires, select **OK** to stop the alert.

Use the stopwatch

1. In Menu mode, select **Stopwatch**.
2. Select **Start** to begin and record lap times.
3. Select **Lap** to record lap times.
4. When you are finished, select **Stop**.
5. Select **Reset** to clear recorded times.

Look up words in a dictionary

Learn to look up English words in your dictionary.

Look up words

1. In Menu mode, select **Dictionary**.
2. Select **Search**.
3. Enter an English word and select **Done**.
4. Select the word.

5. To add the word to your vocabulary list, select **Save**.

View the history

1. In Menu mode, select **Dictionary**.
2. Select **More** → **History**.

View your vocabulary list

1. In Menu mode, select **Dictionary**.
2. Select **More** → **My vocabulary**.

Test your vocabulary

1. In Menu mode, select **Dictionary**.
2. Select **More** → **Review**.
The meaning of the word you saved to your vocabulary list will appear.

3. Select **Answer** to enter a word that corresponds to the meaning of the word and select **Done**.
 - To check the answer, select **Show answer**.
 - To skip to the next word, select **Next**.

Create a new task

1. In Menu mode, select **Task**.
2. Select **Create**.
3. Enter the details of the task and select **Save**.

Create a new memo

1. In Menu mode, select **Memo**.
2. Select **Create**.
3. Enter your memo text and select **Done**.

Manage your calendar

Learn to change the calendar view and create events.

Change the calendar view

1. In Menu mode, select **Calendar**.
2. Select **View by** → **Day** or **Week**.

Create an event

1. In Menu mode, select **Calendar**.
2. Select **Create** → an event type.
3. Enter the details of the event as required and select **Save**.

View events

To view events of a specific date,

1. In Menu mode, select **Calendar**.
2. Select a date on the calendar.
3. Select an event to view its details.

To view events by event types,

1. In Menu mode, select **Calendar**.
2. Select **More** → **Event list** → an event type.
3. Select an event to view its details.

troubleshooting

If you are having trouble with your mobile phone, try these troubleshooting procedures before contacting a service professional.

When you turn on your phone or while you are using the phone, it prompts you to enter one of the following codes:

Code	Try this to solve the problem:
Password	When the phone lock feature is enabled, you must enter the password you set for the phone.
PIN	When using the phone for the first time or when the PIN requirement is enabled, you must enter the PIN supplied with the SIM card. You can disable this feature by using the PIN lock menu.

Code	Try this to solve the problem:
PUK	Your SIM card is blocked, usually as a result of entering your PIN incorrectly several times. You must enter the PUK supplied by your service provider.
PIN2	When you access a menu requiring the PIN2, you must enter the PIN2 supplied with the SIM card. For details, contact your service provider.

The phone prompts you to insert the SIM card.

Ensure that the SIM card is installed correctly.

Your phone displays “No networks found” or “Network error.”

- When you are in areas with weak signals or poor reception, you may lose reception. Move to another area and try again.
- You cannot access some options without a subscription. Contact your service provider for more details.

You enter a number, but the call is not dialed.

- Ensure that you have pressed the Dial key: [📞].
- Ensure that you have accessed the right cellular network.
- Ensure that you have not set call barring for the phone number.

Another caller cannot reach you.

- Ensure that your phone is turned on.
- Ensure that you have accessed the right cellular network.
- Ensure that you have not set call barring for the phone number.

Another caller cannot hear you speaking.

- Ensure that you are not covering the built-in microphone.
- Ensure that the microphone is close to your mouth.
- If using a headset, ensure that it is properly connected.

The phone beeps and the battery icon flashes.

Your battery is low. Recharge or replace the battery to continue using the phone.

The audio quality of the call is poor.

- Ensure that you are not blocking the phone's internal antenna.
- When you are in areas with weak signals or poor reception, you may lose reception. Move to another area and try again.

You select a contact to call, but the call is not dialed.

- Ensure that the correct number is stored in the contact list.
- Re-enter and save the number, if necessary.

The battery does not charge properly or sometimes the phone turns itself off.

- The battery terminals may be dirty. Wipe both gold-coloured contacts with a clean, soft cloth and try charging the battery again.
- If the battery will no longer charge completely, dispose of the old battery properly and replace it with a new battery.

Your phone is hot to the touch.

When you use applications that require more power, your phone may heat up.

This is normal and should not affect your phone's lifespan or performance.